

# Service News 2019/nr 3

## Minor corrections of the manuals for Argos / Nautilus 2

We have made some corrections of the manuals and you can find the updated version in the **Dealer information**.

The corrections are:

- Setting in **C7, Slow agitation %**, for both robot and conventional use, has been changed to 100%.
- Settings in **D17, Heater temp**, has been changed to 60°C to secure a good cleaning result when having electrical heater installed at the tank.

You will find them as the picture below shows.



In case of questions and comments about the content in this Service News please contact:

Wedholms technical group

Mail: [support@wedholms.se](mailto:support@wedholms.se)

Mobile: +46 155 280 382

In case of questions about ordering of spare parts and Aftermarket products please contact:

Mail: [spareparts@wedholms.se](mailto:spareparts@wedholms.se)

Phone: +46 155 280 381